Test Scenario 1: Enter Airlock from External Environment

# Scenario1: Pass Through Airlock from Outside Environment

## **Scenario Description**

When a user wants to pass through the airlock from the outside environment, and the Airlock is in Automatic mode, and with both doors already closed. The airlock must safely open the outer door, followed by opening the inner door and completing the action by closing the inner door.

#### **Version Control**

Versio n #	Date	Author	Description
0.1	01/01/2006	Corie Rhodes	Initial Draft
1.0	01/10/2006	Corie Rhodes	Initial Version

### **Test Scripts**

The following scripts will cover this scenario:

- 1.1 <u>FATLowerEnvironmentPressure</u> Test the airlock in auto mode to ensure a user can pass through the airlock when the environment pressure is less than the cabin pressure.
- 1.2 <u>FATGreaterEnvironmentPressure</u> Test the airlock in auto mode to ensure a user can pass through the airlock when the environment pressure is greater than the cabin pressure.
- 1.3 <u>FATManualModeGreaterEnvironmentPressure</u> Test the airlock in manual mode to ensure a user can pass through the airlock when the environment pressure is greater than the cabin pressure.
- 1.4 <u>FATManualModeLowerEnvironmentPressure</u> Test the airlock in manual mode to ensure a user can pass through the airlock when the environment pressure is less than the cabin pressure.

#### **Use Case**

A user passes through the Airlock.

Test Scenario 1: Enter Airlock from External Environment

## Script 1.1: Auto Mode - Environment Pressure Lower than Cabin Pressure

## **Script Description**

The test will follow the following steps:

- 1. Open the Inner Door
- 2. Open the Outer Door
- 3. Close the Outer Door

## Testing Requirements

This test script covers the following specific testing requirements:

- The environment pressure should be less than the cabin pressure
- The Airlock should be in Automatic mode
- The test should begin with both doors closed
- The Airlock should finish the test in a SEALED state
- The cabin pressure should be unchanged
- The Airlock pressure should be the same as the environment pressure

## Setup

- 1. Airlock must exist, with both doors closed and be in auto mode.
- 2. Environment pressure must be lower than the cabin pressure.

#### Test Data

Data	Value		
Lock Sensor	lockSensor: 1		
Inner Door External Sensor	innerDoorExternalSensor: 3.3		
Outer Door External Sensor	outerDoorExternalSensor: 2.5		
Airlock Outer Door State	airLock.isOuterDoorClosed: true		

Page 2 of 6 | 12/8/22 | Author: Corie Rhodes

#### Test Scenario 1: Enter Airlock from External Environment

Airlock Inner Door State	airLock.isInnerDoorClosed: true	
Airlock State	airLock.isSealed: true	
Airlock Mode	airLock.isInAutoMode: true	

## **Teardown**

- Make sure airlock has both doors in a 'CLOSED' state, the airlock is in manual mode and that the airlock state is 'SEALED'.
- Make sure pressure sensor values are reset to their original values.

## Script Steps

Step #	Test Action	Expected Results	Pass/ Fail
1	Toggle operation mode (Enter "tm")	Airlock mode is set to Automatic.	Pass
2	Open internal door (Enter "oi")	Internal door is opened, airlock set to "UNSEALED".	Pass
3	Open external door (Enter "ox")	Internal door is closed and the external door is opened. Airlock remains in "UNSEALED" state.	Pass
4	Close external door (Enter "cx")	Inner door closed and airlock set to "SEALED" state. Airlock pressure is the same as the environment pressure.	Pass

Test Scenario 1: Enter Airlock from External Environment

## Test Execution

Date/Time	Tester	Test ID	Test Phase	Status
08/12/2022	Corie Rhodes	corierhode s1	System Cycle 1	Passed

**Test Scenario 1: Enter Airlock from External Environment** 

#### **Screenshots**

#### corierhodes1:

```
Airlock: state: SEALED, mode: MANUAL
Exterior PressureSensor: pressure: 0.5 bar
Lock PressureSensor: pressure: 1.0 bar
Interior PressureSensor: pressure: 1.0 bar
Exterior Door: state: CLOSED, external pressure: 0.5 bar, internal pressure: 1.0 bar,
Interior Door: state: CLOSED, external pressure: 1.0 bar, internal pressure: 1.0 bar
```

When the program starts, the airlock is in manual mode, both doors are closed and the airlock is set to SEALED.

```
Airlock: <a href="mailto:state">state</a>: SEALED, mode: AUTO
Exterior PressureSensor: pressure: 0.5 bar
Lock PressureSensor: pressure: 1.0 bar
Interior PressureSensor: pressure: 1.0 bar
Exterior Door: state: CLOSED, external pressure: 0.5 bar, internal pressure: 1.0 bar,
Interior Door: state: CLOSED, external pressure: 1.0 bar, internal pressure: 1.0 bar
```

The user enters "tm" which toggles the airlock to auto mode.

```
Airlock: state: UNSEALED, mode: AUTO
Exterior PressureSensor: pressure: 0.5 bar

Lock PressureSensor: pressure: 1.0 bar
Interior PressureSensor: pressure: 1.0 bar
Exterior Door: state: CLOSED, external pressure: 0.5 bar, internal pressure: 1.0 bar,
Interior Door: state: OPEN, external pressure: 1.0 bar, internal pressure: 1.0 bar
```

The user then enters "oi" which triggers the airlock to equalize the airlock pressure with the external pressure and opens the internal door.

```
Airlock: state: UNSEALED, mode: AUTO
Exterior PressureSensor: pressure: 0.5 bar
Lock PressureSensor: pressure: 0.5 bar
Interior PressureSensor: pressure: 1.0 bar
Exterior Door: state: OPEN, external pressure: 0.5 bar, internal pressure: 0.5 bar,
Interior Door: state: CLOSED, external pressure: 1.0 bar, internal pressure: 0.5 bar
```

The user then enters "ox" which triggers the airlock to close the external door, equalize the airlock pressure with the external pressure and opens the internal door.

```
Airlock: state: SEALED, mode: AUTO
Exterior PressureSensor: pressure: 0.5 bar

Lock PressureSensor: pressure: 0.5 bar
Interior PressureSensor: pressure: 1.0 bar
Exterior Door: state: CLOSED, external pressure: 0.5 bar, internal pressure: 0.5 bar,
Interior Door: state: CLOSED, external pressure: 1.0 bar, internal pressure: 0.5 bar
```

#### Test Scenario 1: Enter Airlock from External Environment

The user then enters "cx" which triggers the airlock to close the external door. Leaving the airlock in a state which has both doors closed, sealed and the lock sensor pressure is the same as the external pressure.

#### Teardown:

```
Airlock: state: SEALED, mode: MANUAL
Exterior PressureSensor: pressure: 0.5 bar
Lock PressureSensor: pressure: 1.0 bar
Interior PressureSensor: pressure: 1.0 bar
Exterior Door: state: CLOSED, external pressure: 0.5 bar, internal pressure: 1.0 bar,
Interior Door: state: CLOSED, external pressure: 1.0 bar, internal pressure: 1.0 bar
```